

SEFAR Architecture fabric&glass

SEFAR Architecture VISION | fabric & glass is a range of high precision fabrics, made from synthetic black monofilament yarn, metal coated, at least on one side coated and optionally printed.












DOWNLOADS

Product Information

Application

SEFAR Architecture VISION fabric is part of a glass laminate, covered in-between two panes of glass and two interlayer foils, fully embedded and protected towards environmental influences. Applicable for flat, as well as for curved glass. SEFAR Architecture VISION fabric is part of a glass laminate.



For exterior and interior applications such as:

- Façades
- Balustrades
- Glass canopies
- Privacy sections
- Glass skylights
- Wall panels and
- Glass fins
- gladdings
- Glass louvers
- Glass partition walls



.....

Benefits

Besides the outstanding, lively 3-D appearance of the fabric and it's unique one-way-vision effect, SEFAR Architecture VISION provides a number of clear additional benefits for architects, designers, engineers, owners and users of buildings with glass applications.

The fabric's open area determines the degree of energy transmission and transparency. In addition, the metal coating and color is also instrumental for the reduction of energy transmission.

■ Reduction of SHGC / ■ Privacy

g-value Lively 3-D

■ Providing shading appearance

■ Glare protection ■ Design, creativity &

■ Bird strike protection function

One-way-vision effectActive safety due to

laminated glass

Patented product



PROJECTS



University, Sydney, AU

New teaching and learning facility and extensive Podium refurbishment of the with Vision heritage RD Watt Building. 140/50.





World Trade Center 3, NYC, US

Podium facade designed with Vision fabric AL 140/50.

Reference: World Trade Center 3



Midtown Jalisco, Guadalajara, MX

Mixed use commercial building with Copper printed Vision fabric in the facade.

Reference:
Midtown Jalisco



World Trade Center 3, NYC, US

Elegant entrance atrium and elevator banks.

Reference: WTC, NYC





Dollar Bay, London, UK

Like a beacon in the waterfront area with one and both sides printed Vision fabric on the ground floor.

Dal Mainz, DE

Glass fins with laminated Vision fabric.

Reference: Dal Mainz

Reference: Dollar Bay



2100 K Street, Washington, US

172 glass fins for the headquarters of the International Finance Corporation.

Reference: 2100 **K Street**



School Building Horw, CH

After the renovation of the school building, the rhythmic interaction of colored glasses creates a distinctive and unique appearance.

Reference: **School Building**



Balustrades in Corporate Office, Richmond, AU

Golden printed Vision fabric has been laminated into the glass of the

Reference:
Corporate Office



Skybridge, New York, US

The SEFAR VISION fabric interlayer protects the skybridge from the heat and glare of the sun while providing unobstructed views of the city.

- Reference: Skybridge
- Additional information
- More details...



Ginza Six, Tokyo, JP

This facade layout was chosen, as they wanted a design using glass which has a texture resembling a metal look.

In the hotel on the renowned Willow Cre Vineyard the SEFAR Architecture VISION

Reference: Ginza Six, Tokyo



Jackalope Hotel, Merricks North, AU

In the hotel on the renowned Willow Creek Vineyard the SEFAR Architecture VISION fabric laminated glass makes for an impactful staircase and balustrade material.

Reference:
Jackalope Hotel



Hyundai Motors R&D Center, Gyeonggi-do, KR

The main reason to use the Vision fabric was privacy shield from exterior and to get a good for the condominium view from inside.

Reference: **Hyundai Center**



City Walk building in Dubai with depth exterior curtain wall appearance to reduce glare and solar heat gain owners.

Reference: City Walk



Nevada Labor Building, Reno, US

The State of Nevada required a new cafeteria for its staff and created an business hub, providing open and pleasant space to reduce energy costs while providing ample daylight.

Reference: **Nevada Labor Building**



International Finance Center, Jersey, UK

Half of the 3'300 m² facade of the world-class environmentally sustainable Grade A office and retail space, is equipped with floor-toceiling windows laminated with VISION AL 260/50B fabric.

Reference: Jersey **Finance Center**



Nerima School, Tokyo, JP

The covered corredor The intent was privacy protects students from rain and to light from the edge and sun. of IGU, using the fabric to

Reference:
Nerima School



Goldin Financial Global Center, Kowloon Bay,

The intent was privacy and to light from the edge of IGU, using the fabric to scatter the light to achieve a glowing effect on the surface of glass.

Reference: Goldin Financial Global Center



UBS Broadgate Elevators, London, UK

Vision fabric laminated used for wall claddings

Reference: UBS Broadgate Elevators



University of Hertfordshire, Hatfield, UK

Science building with Insulated Double Glazed units laminated with Sefar Vision fabrics.

Reference: University of Hertfordshire



Library Birmingham, UK Australian Post Office,

Contemporary aesthetic with high level of glazing

Reference:
Library
Birmingham



Australian Post Office, Westin Melbourne, AU

The glass building of the

Reference:
Australian Post
Office



Novartis Research Facility, Cambridge, US

Glass Louvers laminated with both sides coated/ printed Vision fabric for improvements.

Reference:
Novartis
Research Facility



Da Heng Building, Taichung, TW

The project specific SEFAR Architecture VISION PR 260/50 metallic grey fabric was laminated in the lower curtain wall for a total of over 1000 sgm.

Reference: Da Heng Building



Dun Laoghaire Library, Dublin, IR

The windows of the Dun Laoghaire library are more SEFAR Architecture conventional openings, partly shaded with louvres, laminated into the exterior which are laminated with SEFAR Architecture

Reference: Dun **Laoghaire Library**

Reference: **Airport Keflavik**



Georgstrasse, Hannover, Construction company DE

The aspect of the sunscreens across the entire facade was as important as the change of efficient but also offers image in an innovative way.

Reference: Georgstrasse



The building consists of a

glass facade, featuring

VISION. This fabric is

glass facade, acting as a

sunscreen and having a

van Roey, Het Looi Rijkevorsel, BE

The innovative system is not only functionally design freedom through numerous color and shaping options. Vertical and horizontal glass fins with laminated SEFAR Architecture VISION Fabric were installed across four levels of the building's facade.

Reference: Het Looi



Animal Protection Office, Zurich, CH

The glass facade with 1'400 m² of laminated SEFAR Architecture VISION Fabric provides an ideal habitat for

Reference: Zurich **Animal Protection** Office



Swiss Railway Main Office Building, Bern Wankdorf, CH

The facades consist of colored, moveable glass slats which transform the visual appearance of the animals and humans alike. building as the sun moves across the sky.

Reference: Swiss Railway Main Office Building



Europaallee 21, Construction Area C, Zurich, CH

The building complex is formed from four structures grouped together around an open courtyard in the shape of a it's located. The facade windmill sail. Each building was designed by a different architect so is therefore different in appearance.

Reference: Europaallee, **Construction Area**



C Quadro, Executive Building, Udine, IT

The ultra-modern, elegant 'C Quadro Executive Building' lends a new sparkle and gives a new face to the district where laminated with the SEFAR VISION fabric subtly picks up on the set piece - the familiar silhouette - and deliberately mirrors the characteristically irregular city skyline.

Reference: C **Quadro, Executive Building**



Suurstoffi Offices. Rotkreuz, CH

Novartis Corporation's new Swiss Headquarters at 'Suurstoffi' Rotkreuz is fitted with different colored SEFAR Architecture VISION fabric.



Würth Building, Rorschach, CH

Five-storey administration building directly at the lakeside.

Reference: Würth **Building**

Reference: **Suurstoffi Offices**



10 Brock St, NEQ, Regent's Place, London, BKK headquarters, UK

SEFAR Architecture VISION fabric is used to contrast with the profiled, anodized stainless steel behind glass on the south facade, while the east/ west façades are shaded with vertical fins of glass and translucent coated Sefar fabric. These fins vary in depth to create a wave pattern across the façade.

Reference: Regent's Place, London



Crystal of sylvinite for Minsk, BY

The general ideology of the office building was to employ maximum color, light and glass. The intention of the 8 floor building was to symbolize a crystal of sylvinite.

Reference: Crystal of sylvinite for BKK



Prime Tower Room divider, Zurich, CH

Double side coated SEFAR Architecture VISION fabric as room divider between the meeting room and corridor restaurant Clouds. of a bank.

Reference: Prime **Tower Room divider**



Fashion House, Madrid, **ES**

The glass curtain wall is reminiscent of a threedimensional checkerboard. This is achieved using alternating Archive. In the original panels of clear laminated safety glass and panels embedded with VISION fabric.

Reference: Fashion **House Madrid**



Prime Tower Ceiling, Zurich, CH

The SEFAR Architecture VISION fabric attached to metal ceiling panels build a cloudy ceiling in the

Reference: Prime **Tower Ceiling**



Haus der Stadtgeschichte, Heilbronn, DE

The renovated 'Haus der Stadtgeschichte' is now part of the Heilbronn City building, the interior areas were uncomfortably warm so much consideration was given to providing sun protection when planning the renovation.

Reference: City Archive, Heilbronn





Design Festival, London, UK

The installation 'Two Lines' by David Chipperfield Architects with SEFAR Architecture VISION fabric simultaneously delighted and intrigued visitors to Size+Matter.

Reference: London Design Festival



FABRIC ASSORTMENT AND STANDARD COLORS





AL 140/25

PR 140/25 Copper CPST






PR 140/25 Gold GDST

AL 140/25 Glass





PR 140/25 Copper, Glass PR 140/25 Gold, Glass





AL 140/50

PR 140/50 Copper CPST






PR 140/50 Gold GDST AL 140/50 Glass








PR 140/50 Copper, Glass PR 140/50 Gold, Glass





AL 260/30

PR 260/30 Copper CPST






PR 260/30 Gold GDST

AL 260/30 Glass





PR 260/30 Copper, Glass PR 260/30 Gold, Glass





AL 260/55

PR 260/55 Copper CPST







PR 260/55 Gold GDST

AL 260/55 Glass






PR 260/55 Copper, Glass PR 260/55 Gold, Glass

COLOR DESIGN OPTIONS

Pattern examples / Customized patterns





pattern

PR 260/55 black & silver PR 260/55 Leopard blue pattern






PR 260/55 red pattern

PR 260/55 Tiger red pattern





PR 260/55 turquoise scquare pattern



PR 260/55 red dots pattern





Silver

Copper CPST



Gold GDST

Color samples or customer specific colors



By means of digital printing, the coated fabric sides can be decorated with individual designs or any specific color. In



addition to the one-side coating and printing, both sides can be coated and printed (e.g. for glass-fins or -louver, glass partition walls), even with different colors or designs, without any showthrough on the reverse side.

SEFAR VISION – A fusion of unique aesthetics and function

One-way-vision effect

The so-called one-way-vision effect is obviously the main aspect of the product. It provides an exceptional range of design possibilities on the outer face of the glass pane for architects and façade designers, on the basis of a unique, exciting and lively 3-D appearance – without disturbing the view from the inside to the outside. Find it out by sliding the pictures:.



Outside view – Project BKK, Minsk (Belarus)



View from inside – BKK Building, Minsk



Example for visual appearance from outside




View from inside

Energy transmission in laminated glass in combination with SEFAR VISION fabric

The fabric's open area determines the degree of energy transmission and transparency. In addition, the metal coating and color is also instrumental for the reduction of energy transmission.







SEFAR Architecture – Brochures & Documents

Table of values (, 0 kb)

Bird protection (, 0 kb)

Our vision

CONTACT

Please call us for further information: Phone CH: +41 71 898 5700

Send mail





Locations



Sefar Filter Pure (Pty) Ltd

Postnet Suite #242 Private Bag X18 North Riding, 2162 South Africa

Phone: +27 11 708 2485/6/7

Fax: -